

## KRAIBURG profiKURA P / KURA P

### Prerequisites:



#### Concrete area:


- Min. 10 cm thick and smooth
- No holes
- No ridges
- profiKURA: max. 6% slope
- KURA: max. 3% slope

#### Mastic asphalt:

- Max. 3 cm thick
- Ground: min. 10 cm thick, solid concrete layer

#### Mats:


Even temperature:  
min. 5°C to max. 30°C  
(store according to initial temperature)




The mastic asphalt will more or less change shape during use.

### You will need:


#### Measuring:




#### Marking:



#### Cutting:



#### Drilling and installing:



#### KRAIBURG fixings:



##### Concrete:

Nail plugs  $\varnothing$  10 x 80 mm - A2 with  
Washers  $\varnothing$  30 mm - A2

##### Mastic asphalt:

Nail plugs  $\varnothing$  10 x 120 mm - A2 with  
Washers  $\varnothing$  30 mm - A2

(Fixings are part of the delivery)


#### ! Scraper:

Either use scraper facilities specially adapted to rubber flooring or with structural alterations: Adapt existing scraper facilities according to the **KRAIBURG guidelines for manure scrapers for rubber flooring on paved floors**




#### Mobile manure removal and compatibility with vehicle traffic:



Comply with the **KRAIBURG vehicle traffic specifications**



## 1 Install mats




Distance to the side edge: 2 cm (min. 1 cm - max. 6 cm)




#### With central guide:

The mat side with 4 fixing points is always located along the **central guide**.




Distance to the guide channel: 1 cm



#### Without central guide:


The same number of fixing points are always located along the same **side**.






Loosely interconnect the mats, lift them slightly and pull them apart gently

**! Avoid creating tension!**




**DO NOT PRESS!**

**DO NOT PULL ON ONE SIDE ONLY!**




**! At low temperatures:** Pull the puzzle interlock system apart to create a visible gap

## 2 Adapt



If necessary, cut mats to fit




Any excess puzzle pieces can be cut off at the start and end of an area.



**Tips for cutting:**

- Moisten the blade slightly
- Pull mat parts apart slightly
- Use pliers to grab small pieces
- **A jigsaw is best suited for cutting profiKURA**




## 3 Fix


**! Concrete: Nail plugs  $\varnothing$  10 x 80 mm**  
**Mastic asphalt: Nail plugs  $\varnothing$  10 x 120 mm**

**! If some mats are cut to fit on site:** Fix additionally at comparable distances along the cutting edge!



Fix through the pre-fabricated holes:




Drill



Knock plastic plugs in flush





Knock in nails and washers until they are seated evenly and firmly and are slightly countersunk



**Tip:**

Check if the fixing can be felt by sliding a flat metal object (e.g. a hammer) over it. If the fixing can still be felt, knock it in deeper!



A small gap should be visible

**! Do not knock in too deep!**

Tension should not develop, the mat should not bulge!

