

KRAIBURG WELA / WELA Puzzle

Prerequisites:




Concrete area:

- No holes
- No ridges
- Min. 3% slope

Mats:


Even temperature:
min. 5°C to max. 30°C
(store according to initial temperature)




For animal well-being, a certain amount of bedding is necessary to absorb moisture (e.g. soft milled straw or mineral material)!

You will need:


Measuring:




Marking:



Cutting:



Drilling and installing:




KRAIBURG fixings:



- Framing plugs \varnothing 10 x 80 mm with
- Hexagon screws (AF 13) - A2
 - Washers \varnothing 40 mm - A2

(Fixings are part of the delivery)

1 Placement line



Draw a placement line at the front


Tip: Use a chalk line

Measure from the rear concrete edge


2 Install row of mats completely

i Start from the center of the row of stalls and install on the right and on the left

Prepare to fix at the front edge



Puzzle interlock system or joint roughly underneath the divider (max. +/- 8 cm)




Rear concrete edge:
5 cm installation distance!

i The distance will decrease considerably within the first days after installation


! Cutting out pockets for pillars or the like is not possible!



About ② Install row of mats completely




Push mats together loosely




Loosely interconnect the mats, lift them slightly and pull them apart gently

! Avoid creating tension!


DO NOT PRESS!



DO NOT PULL ON ONE SIDE ONLY!




③ Fix




Fix at the front edge four times through the prefabricated fixing points


! Always make sure the front edge of the mat is located on the line.
Re-adjust, if necessary.



Drill



Knock the plastic plugs in flush



Tighten screws and washers

! Tighten screws until they are seated evenly and firmly and are slightly countersunk. **Do not overtighten!**