

KRAIBURG mats for flushing manure removal on large collecting yards

profiKURA Flush / profiKURA Flush SUN / KURA Flush / KURA Flush SUN

Prerequisites:



Concrete area:


- Min. 10 cm thick and smooth
- No holes
- No ridges
- Max. 8% slope

Mastic asphalt:

- Max. 3 cm thick
- Ground: min. 10 cm thick, solid concrete layer

Mats:


Even temperature:
min. 5°C to max. 30°C
(store according to initial temperature)




The mastic asphalt will more or less change shape during use.

You will need:


Measuring:




Marking:



Cutting:



Drilling and installing:



KRAIBURG fixings:




Concrete:


Nail plugs \varnothing 10 x 80 mm - A2 with
Washers \varnothing 30 mm - A2

Mastic asphalt:


Nail plugs \varnothing 10 x 120 mm - A2 with
Washers \varnothing 30 mm - A2

(Fixings are part of the delivery)

 **profiKURA Flush / KURA Flush**
on large collecting yards with
flushing manure removal without
extreme solar radiation




profiKURA Flush SUN / KURA Flush SUN
(version with expansion slits) on large collecting
yards with flushing manure removal with extreme
solar radiation




1 Install mats

 **Start at a straight edge!**




Install the complete area

Fixing holes




Distance to the
side edge: 1 - 6 cm




Distance between
the mats: 1 - 2 cm



2 Adapt



If necessary, cut mats to fit




Cut in only in the water running direction!



Tips for cutting:

- Moisten the blade slightly
- Pull mat parts apart slightly
- Use pliers to grab small pieces
- **A jigsaw** is best suited for cutting **profiKURA**




3 Fix


! Concrete: Nail plugs \varnothing 10 x 80 mm
Mastic asphalt: Nail plugs \varnothing 10 x 120 mm

! If some mats are cut to fit on site: Fix additionally at comparable distances along the cutting edge!



Fix through the pre-fabricated holes:




Drill



Knock the plastic plugs in flush





Knock in nails and washers until they are seated evenly and firmly and are slightly countersunk



Tip:

Check if the fixing can be felt by sliding a flat metal object (e.g. a hammer) over it. If the fixing can still be felt, knock it in deeper!



A small gap should be visible



Do not knock in too deep!

Tension should not develop, the mat should not bulge!

